

Vibrastar 40,50,60

Spare parts list

Poker vibrators

Vibrastar 40, 50, 60



General information

This spare parts list applies to the following:

Part number	Description
967938101	POKERS Vibrastar 40 42 V 3-phase 200 Hz
967938102	POKERS Vibrastar 50 42 V 3-phase 200 Hz
967938103	POKERS Vibrastar 60 42 V 3-phase 200 Hz

Use only authorized parts. Any damage or malfunction caused by the use of unauthorized parts is not covered by Warranty or Product Liability. Any unauthorized use or copying of the contents or any part thereof is prohibited. This applies in particular to trademarks, model denominations, part numbers, and drawings.

Instructions for use

This spare parts list contains no safety regulations and is merely intended to assist in the ordering of spare parts.

For information about operating, servicing, or repairing, the relevant Safety and operating instructions must be consulted at all costs.

Please observe the safety instructions listed in the relevant Safety and operating instructions!


Spare parts list

Vibrastar 40 1
Vibrastar 50 3
Vibrastar 60 5

Kits

Maintenance kit for switch box7

Spare parts list Vibrastar 40




Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
1	594616701	Vibrating element, complete	1	
2	594617001	End cap	1	
3	594286301	Retaining ring	1	
4	594617301	Bearing	2	
5	594859501	Eccentric	1	
6	594617201	Rotor	1	
7	594617101	Stator	1	
8	594289001	Gasket	1	
9	594616401	Flexible sheathing	1	
10	594618001	Thrust ring	1	
11	594616501	Thrust screw	1	
12	--	Oil, 0.005 litre , 0.001 gallon. Shell Tellus T46	1	
13	594281701	Clamp	2	
14	594257501	Thermo insulating	3	
15	595118501	Splicing sleeve	3	
16	594257101	Protective hose, 0.08 m , 3.1 in., Sold per meter.	1	A
17	594286401	Clamp	4	
18	594287701	Wire	1	B
19	594257101	Protective hose, 0.08 m , 3.1 in., Sold per meter.	1	C
20	594859601	Hose	1	D
21	594256801	Flexible sheeting	1	
22	595468901	Cable	1	
23	594604701	Plug	1	
24	594257701	Wire end	9	
25	594255201	Clamp	1	
26	594619301	Gland	1	
27	594615701	Screw	2	
28	595117501	O-ring	2	
29	594615301	Switch box	1	
30	594615601	Rubber membrane	1	
31	594630401	Switch	1	
32	594615501	Rubber gasket	1	
33	594623101	Hose	2	E
34	594630601	Cover	1	
35	-	Socket screw, M5 x 20 mm		

Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Spare parts list Vibrastar 50




Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
1	594616801	Vibrating element, complete	1	
2	594617401	End cap	1	
3	594278001	Snap ring	1	
4	594617501	Bearing	2	
5	595194401	Eccentric	1	
6	595480101	Rotor	1	
7	595202701	Stator	1	
8	594289001	Gasket	1	
9	594290401	Flexible sheating	1	
10	594287501	Thrusting	1	
11	594287301	Thrust screw	1	
12	--	Oil, 0.01 litre, 0.003 gallon. Shell Tellus T46.	1	
13	594281701	Clamp	2	
14	594257501	Thermo insulating	3	
15	595118501	Splicing sleeve	3	
16	594257101	Protective hose, 0.08 m , 3.1 in., Sold per meter.	1	A
17	594286401	Clamp	4	
18	594287801	Wire	1	B
19	594257101	Protective hose, 0.08 m , 3.1 in., Sold per meter.	1	A
20	594388401	Hose	1	C
21	594256801	Flexible sheeting	1	
22	595468901	Cable	1	
23	594604701	Plug	1	
24	594257701	Wire end	9	
25	594255201	Clamp	1	
26	594619301	Gland	1	
27	594615701	Screw	2	
28	595117501	O-ring	2	
29	594615401	Switch box	1	
30	594615601	Rubber membrane	1	
31	594630401	Switch	1	
32	594615501	Rubber gasket	1	
33	594623101	Hose	2	D
34	594630601	Cover	1	
35	-	Socket screw, M6 x 20 mm		

Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Spare parts list Vibrastar 60



Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
1	594616901	Vibrating element, complete	1	
2	594617601	End cap	1	
3	595144401	Circlip ring	1	
4	594617801	Bearing	2	
5	594617901	Eccentric	1	
6	594631401	Rotor	1	
7	595480201	Stator	1	
8	594289001	Gasket	1	
9	594290401	Flexible sheating	1	
10	594287501	Thrusting	1	
11	594287301	Thrust screw	1	
12	--	Oil, 0.015 litre, 0.004 gallon. Shell Tellus T46.	1	
13	594281701	Clamp	2	
14	594257501	Thermo insulating	3	
15	595118501	Splicing sleeve	3	
16	594257101	Protective hose, 0.08 m , 3.1 in., Sold per meter.	1	A
17	594286401	Clamp	4	
18	594287801	Wire	1	B
19	594257101	Protective hose, 0.08 m , 3.1 in., Sold per meter.	1	A
20	594388401	Hose	1	C
21	594256801	Flexible sheeting	1	
22	595468901	Cable	1	
23	594604701	Plug	1	
24	594257701	Wire end	9	
25	594255201	Clamp	1	
26	594619301	Gland	1	
27	594615701	Screw	2	
28	-	O-ring, 4.1 x 1.6 mm , 0.16 x 0.06 in. NBR (70 shore)	2	
29	594615401	Switch box	1	
30	594615601	Rubber membrane	1	
31	594630401	Switch	1	
32	594615501	Rubber gasket	1	
33	594623101	Hose	2	D
34	594630601	Cover	1	
35	-	Socket screw, M6 x 30 mm	1	

Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Kits Maintenance kit for switch box

NO EXPLODED VIEW
AVAILABLE
FOR THIS BOM

Item	Part No.	Name	Qty	L
1	594619601	Maintenance kit for switch box	1	
2	594615501	Rubber gasket	1	
3	594615601	Rubber membrane	1	
4	594615701	Screw	2	
5	595117501	O-ring	2	

Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Any unauthorized use or copying of the contents or any part thereof is prohibited.
This applies in particular to trademarks, model denominations, part numbers, and drawings.